

Step 1: Open the back lid

Step 2: Torx 922-8646 screws (6 screws - Make them loose, don't remove them)

Step 3: now close the lid of your macbook pro and adjust the lid and body properly.

Step 4: Open lid and tight all 6 screws.

Step 5: Done

